



491037 - 230v Relay Board Assembly

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	421015	Relay Board	1
2	425014	230v To 24v Transformer	1
3	422006	10 Amp Solid State Relay	4
4	444018	Relay	3
5	444019	Relay Socket	3
6	444020	Relay Clip	3
7	426002	DIN Rail	0.127m
8	444022	DIN Rail Stop	2
9	444021	DIN Rail Spacer	2



**491038 - 230v Cook and Hold Control Panel Assembly
w/o INTERIOR LIGHT SWITCH**
**491041 - 230v Cook and Hold Control Panel Assembly
w/ INTERIOR LIGHT SWITCH**

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	410036	Cook and Hold Control Panel	1
2	441050	Emergency Stop Switch	1
3	441049	Burner Lit Indicator	1
4	441055	High-Limit Reset Button	1
5	443009	Pneumatic Rotisserie Advance Switch	1
6	431025	Cook and Hold Digital Thermostat	1
7	415049	Control Panel Overlay	1
8	441047	Interior Light Switch (with optional glass doors)	1
	073039	Control Panel Gasket (back of panel)	2



TITLE:

**230v Control Panel
Exploded View**

Models: All 230v Gas Rotisserie

SIZE	DWG. NO.	REV
A	SPEXpl-E002	1

NAME	DATE	SCALE: 1:5	WEIGHT:	SHEET 1 OF 1
CSN	6-27-16			